


KHM 2x400 PS



Instruction manual



Dear Customer,

We wish to thank you for having bought this product.

Please take time to read this manual and familiarize yourself with the machine before attempting to use it.

If you should have questions or problems please contact the nearest authorized Service Center. They have the experience and original spare parts. The use of non-original spare parts will void the warranty.

TABLE OF CONTENTS


| DESCRIPTION | PAGE |
|--|----------------------|
| <u>GENERAL INFORMATION</u> | |
| INFORMATION ABOUT THIS MANUAL | M 2 |
| DESCRIPTION - SYMBOLS | M 2.1 |
| PRECAUTIONS - GENERAL | M 2.5 |
| PRECAUTIONS - ENGINE DRIVEN WELDERS | M 2.5.1 |
| TRANSPORT | M 4.2 |
| ASSEMBLY OF SITE TOW FOR KHM 2x400 | M 6.8 |
| INSTALLATION INFORMATION | M 2.6 |
| INSTALLATION | M 2.7 |
| <u>OPERATION</u> | |
| UNPACKING | M 3 |
| TECHNICAL DATA AND MACHINE DESCRIPTION | M 1.5, M 1.6 |
| PREPARING THE UNIT | M 20 |
| STARTING AND STOPPING THE ENGINE | M 21 |
| CONTROLS | M 31 |
| OPERATING | M 32... |
| USE - WELDING DIGITAL CONTROL | M 33.1, 33.2, 33.3 |
| REMOTE CONTROL PHG1A | M 38.9 |
| MAINTENANCE | M 43, M 43.3, M 44.2 |
| STORAGE | M 45 |
| TECHNICAL DATA | M 53 |
| <u>SCHEMATICS AND SPARE PARTS</u> | |
| ORDERING OF SPARE PARTS | R 1 |
| WIRING DIAGRAM – ENGINE EP5 | M 61.1 |
| WIRING DIAGRAM – AUXILIARY 2xY400V / 3xI230V / 3xI110V | M 61.2 |
| WIRING DIAGRAM – WELDING POWER | M 61.3, 61.4 |
| WIRING DIAGRAM – WELDING CONTROL | M 61.5, 61.6 |
| SPARE PARTS | ED6, ED6.1 |
| SPARE PARTS | ED14, ED14.1 |
| SPARE PARTS | ED8, ED8.1 |
| SPARE PARTS | ED9, ED9.1 |
| KIT DECAL | |
| SITE TOW FOR KHM 2x400 | KA12 |
| PHG1A | KD11 |

GENERAL INFORMATION

– In the envelope where you found this manual you will also find an Owner's manual for the engine, and accessories (if required).

This product has been designed for welding and generation of electrical power for tools and other electrical devices used in construction; ANY OTHER USE, is not permitted and we cannot be held responsible for injuries or damages resulting from such incorrect use.

Our products are made in conformity with the safety norms in force in order to avoid injury to persons or damage to the machine or other things.

 **Warranty is not valid if not carried out by ESAB authorized service agent.**

Making modifications to the machine without our written authorization will void the warranty and release us from any liability.


ABOUT THIS MANUAL

Before using the machine please read this manual attentively and follow the instructions contained in it. This will help avoid problems, possible injury and damage to the machine.

The manual is written for experienced, qualified personnel, who are familiar with health and safety laws and related regulations.

This manual is an integral part of the product and should be kept in a safe place so that it will be available for consultation during the life of the product. If the machine is sold the manual should be transferred to the new owner.

Some figures contained in this manual are designed to help identify certain parts and may not correspond to the machine in your possession.

 **Notice:** *the manufacturer may make improvements or modifications to the product or its accessories as described in this manual without updating the manual.*

HEADINGS USED IN THIS MANUAL

The headings used in this manual are designed to call your attention to potential hazards and important aspects of the operation of the machine...



DANGEROUS

Indicates a strong possibility of severe personal injury or death if instructions are not followed.



WARNING

Indicates a possibility of personal injury or equipment damage if instructions are not followed



CAUTION

Indicates that equipment or property damage can result if instructions are not followed.



IMPORTANT



NOTE



ATTENTION

These headings give helpful information about the preparation, operation and care of the machine.



GENERAL SYMBOLS



STOP – Read with great attention



Read with attention



WRENCH - Use the correct tools for the type of work being done

WARNING SYMBOLS



ATTENTION - If this advice is not followed people or things can be hurt or damaged.



HIGH VOLTAGE - Do not touch – risk of injury or death.



FIRE - Risk of fire.



HEAT - Hot surfaces.



EXPLOSIVE - Explosive material or danger of explosion, in general.



NO WATER - Do not use water as it can cause shortcircuits or other damage.



NO SMOKING - Cigarettes, matches or lighters can start a fire or explosion.



ACIDS - Danger of corrosion or burns.

SAFETY SYMBOLS

Use the correct protective devices for the type of welding being done



Use protective clothing, etc. specifically designed for the type of welding being done.

Protect yourself when doing maintenance on the machine



It is advisable to protect yourself when carrying out maintenance, such as filling the battery, refuelling, etc.

Pay attention to safety precautions when moving the machine



Refer to the instructions before moving the machine

Wear indicated safety clothing -



It is compulsory to wear the personal protection items shown when using the equipment.

Use required safety devices -



Safety devices suitable for the type of welding and the location of the job must be used.

Do not use water on electrical fires -



It is prohibited to use water to put out fires in electrical equipment.

Do not touch without having disconnected the electricity -



It is prohibited to work on the machine until the electricity has been turned off.

Welding prohibited -



It is forbidden to weld in areas containing explosive gases.



IMPORTANT

- Read and understand these instructions.
- Before installing, operating or servicing this equipment, read the operating manuals of the welder and of the engine.
- Not observing the information in the manuals can result in personal injury and/or damage to the equipment and other property.
- Respect all safety regulations and laws when operating this equipment.



WARNING

Do not remove or disable protective devices

Removing or disabling protective devices on the machine is prohibited.

Do not use the machine if it is not in good technical condition

The machine must be in good working order before being used. Defects, especially those which regard the safety of the machine, must be repaired before using the machine.



FIRST AID. In case the operator should be sprayed by accident, from corrosive liquids a/o hot toxic gas or whatever event which may cause serious injuries or death, predispose the first aid in accordance with the ruling labour accident standards or of local instructions.

ENGINE FUELLING

- ⇒ Stop engine when fuelling.
- ⇒ Do not smoke, avoid open flames and sparks, and do not use electric tools when fuelling.
- ⇒ Unscrew the fuel cap slowly to let out the fuel vapours.
- ⇒ Do not over-fill the tank.
- ⇒ Avoid spilling fuel on hot engine.
- ⇒ Wipe up spilled fuel before starting engine.
- ⇒ Shut off fuel cock, if present, or remove fuel from tank before moving machine

FOR BATTERY EQUIPPED UNITS ONLY

- ⇒ Sparks may cause the explosion of battery vapours

WATER COOLED ENGINES ONLY

- ⇒ Slowly unscrew the cooling liquid cap of a hot engine to allow vapours to escape.
- ⇒ Hot vapor and heated cooling liquid under pressure can burn face, eyes, skin.

| | |
|-------------------------------|--|
| Skin contact | Wash with water and soap |
| Eyes contact | Irrigate with plenty of water, if the irritation persists contact a specialist |
| Ingestion | Do not induce vomit as to avoid the intake of vomit into the lungs, send for a doctor |
| Suction of liquids from lungs | If you suppose that vomit has entered the lungs (as in case of spontaneous vomit) take the subject to the hospital with the utmost urgency |
| Inhalation | In case of exposure to high concentration of vapours take immediately to a non polluted zone the person involved |



FIRE PREVENTION. In case the working zone, for whatsoever cause goes on fire with flames liable to cause severe wounds or death, follow the first aid as described by the ruling norms or local ones.

EXTINCTION MEANS

| | |
|-----------------------|--|
| Appropriated | Carbonate anhydride (or carbon dioxide) powder, foam, nebulized water |
| Not to be used | Avoid the use of water jets |
| Other indications | Cover eventual shedding not on fire with foam or sand, use water jets to cool off the surfaces close to the fire |
| Particular protection | Wear an autorespiratory mask when heavy smoke is present |
| Useful warnings | Avoid, by appropriate means to have oil sprays over metallic hot surfaces or over electric contacts (switches, plugs, etc.). In case of oil sprinkling from pressure circuits, keep in mind that the inflammability point is very low. |

| WARNING | | | | | CAUTION | |
|----------------|--|--|--|--|----------------|--|
| | | | | | | |
| | | | | | | |

WARNING

THE MACHINE MUST NOT BE USED IN AREAS WITH EXPLOSIVE ATMOSPHERE

PRECAUTIONS

The operator of the welder is responsible for the security of the people who work with the welder and for those in the vicinity.

The security measures must satisfy the rules and regulations for engine driven welders.

The information given below is in addition to the local security norms.



- ▀▀▀▀ Make sure that the area is safe before starting any welding operation.
- ▀▀▀▀ Do not touch any bare wires, leads or contacts as they may be live and there is danger of electric shock which can cause death or serious burns. The electrode and welding cables, etc. are live when the unit is operating.
- ▀▀▀▀ Do not touch any electrical parts or the electrode while standing in water or with wet hands, feet or clothes.
- ▀▀▀▀ Insulate yourself from the work surface while welding. Use carpets or other insulating materials to avoid physical contact with the work surface and the floor.
- ▀▀▀▀ Always wear dry, insulating gloves, without holes, and body protection.
- ▀▀▀▀ Do not wind cables around the body.
- ▀▀▀▀ Use ear protections if the noise level is high.
- ▀▀▀▀ Keep flammable material away from the welding area.
- ▀▀▀▀ Do not weld on containers which contain flammable material.
- ▀▀▀▀ Do not weld near refuelling areas.
- ▀▀▀▀ Do not weld on easily flammable surfaces.
- ▀▀▀▀ Do not use the welder to defrost (thaw) pipes.
- ▀▀▀▀ Remove the electrode from the electrode holder, when not welding.
- ▀▀▀▀ Avoid inhaling fumes by providing a ventilation system or, if not possible, use an approved air breather.
- ▀▀▀▀ Do not work in closed areas where there is no fresh air flow.
- ▀▀▀▀ Protect face and eyes (protective mask with suitable dark lens and side screens), ears and body (non-flammable protective clothes).







TRANSPORT


M
4-2



NOTE

In case you have to move or transport or move the machine, follow the instructions as shown in the figures. Transport the machine **without** petrol in the tank, **without** oil in the engine and **without** electrolyte in the battery. Be sure that the transportation devices are adequate for the size and weight of the machine.





DO NOT TRANSPORT ACCESSORIES OR OTHER ITEMS WHICH COULD INCREASE THE WEIGHT AND/OR CHANGE THE CENTER OF GRAVITY OF THE MACHINE.
DO NOT DRAG THE MACHINE OR TOW IT ON PUBLIC ROADS UNLESS IT IS MOUNTED ON A HOMOLOGATED TRAILER.

Not following these instructions could cause injury or damage to the machine.

“CTL” SITE TOW

The machines provided for assembling the accessory slow towing trolley can be towed up to a **maximum** speed of **40 Kms/hour** on asphalted surfaces.

Towing on public roads or turnpikes of any type **IS EXCLUDED**, because **not** in possession of the requirements by national and foreign traffic norms.





ATTENTION

The accessory cannot be removed from the machine and used separately. It is actioned manually or following vehicles for the transport of loads or anyway for used different from the machine movements.


TRAILERS

The machines provided for assembling the accessory slow towing trolley can be towed up to a **maximum** speed of **40 Kms/hour** on asphalted surfaces.

Driving on public roads or turnpikes of any type **IS EXCLUDED**, because **not** in possession of the requirements by national and foreign traffic norms.

Nota: Lift the machine and assemble the parts as shown in the drawing


CTL 35
CTL 45




When assembling the generating set on the trolley please keep to following instructions

Lift the generating set by means of suitable hook
 Assemble on the machine the towbar complete of
 foot with the x , screws, nuts and washers.
 Assemble the axle to the base of the machine with
 the x screws and relative washers two per part
 so that their supports coincide.
 Insert the wheel on the axle then twist the
 selflocking nut .
 Pump the tyre bringing the pressure to atms for
 the .
 Lower the machine to the ground and place the parking
 foot definitively regulating at the best height .

CTL 35




CTL 45






ATTENTION

Do not substitute the original tyres with other types.



DIESEL ENGINES

· Use in open space with fresh air flow or vent exhaust gases far from the work area.



☞ Assure that the hot air and/or exhaust gas from the machine are vented and are not recirculated in the machine. Hot air and/or exhaust gas which is recirculated will cause overheating of the machine and poor combustion in the engine

☞ Make sure that the machine does not move during operation.

MOVES OF THE MACHINE

☞ At any move check that the engine is **off**, that there are no connections with cables which impede the moves.

PLACE OF THE MACHINE


⚠ ATTENTION

For a safer use from the operator **DO NOT** fit the machine in locations with high risk of flood.


Please do not use the machine in weather conditions which are beyond IP protection shown both in the data plate and on page named "technical data" in this same manual.


POSITIONING THE MACHINE

Place the machine on a level surface at a distance of at least 1,5 m from buildings or other structures.




If the surface is not level be sure that the angle of the machine does not exceed the values shown in the drawings below.





⚠ GENERAL PACKING INFORMATION






Upon receipt of the goods make sure that the product has not been damaged during transport.

In case of damage or missing items you must inform your freight forwarder immediately.



Packing materials must be disposed of according to local regulations.



UNPACKING THE MACHINE

Take the machine out of the carton. Locate the User's manual, which is packed together with the engine manual and accessories in a plastic envelope. This envelope may be under or inside the machine.

Check the rating plate on the machine and confirm that the serial number and model are the same as shown on the packing note invoice.

NB. For further information on preparing the unit for use refer to the related parts of this manual.





TECHNICAL DATA

KHM 2x400 PS

M 1.5

The H x engine driven welder is a unit which function as a current source for arc welding and an electric auxiliary power generator

It is meant for industrial and professional use, powered by an internal combustion engine. It is composed of an engine, alternator, electric and electronic controls, and a protective housing.

Technical data

KHM 2x400 PS

GENERATOR

Table with 2 columns: Parameter (Output three-phase, Output single-phase, Frequency, Cos phi) and Value (40 kVA / 400 V / 57.8 A, etc.)

ALTERNATOR

Table with 2 columns: Parameter (Type, Insulating class) and Value (Self-excited, self-regulated, brushless, three-phase, asynchronous, H)

ENGINE

Table with 2 columns: Parameter (Mark / Model, Type / Cooling system, Cylinders / Displacement, Output max, Speed, Fuel / Fuel consumption, Cooling system capacity, Engine oil capacity, Starter) and Value (PERKINS / 1103C - 33TG3, 4-Stroke / Liquid, 3 / 3300 cm³, etc.)

GENERAL SPECIFICATIONS

Table with 2 columns: Parameter (Battery, Tank capacity, Running time, Protection, Dimensions, Weight, Measured acoustic power, Guaranteed acoustic power) and Value (12V - 100Ah, 102 l, 13 h, IP 44, 2490x1030x1300, 1300 Kg, 93 LWA, 94 LWA)



Dimensions and weight are inclusive of all parts without wheels and towbar.

POWER

Declared power according to IS temperature, relative humidity, altitude m above sea level. It's admitted overload of each hour every h. In an approximative way one reduces of every m altitude and of for every above.

ACOUSTIC POWER LEVEL

ATTENTION: The concrete risk due to the machine depends on the conditions in which it is used. Therefore, it is up to the end user and under his direct responsibility to make a correct evaluation of the same risk and to adopt specific precautions for instance, adopting a I.D. Individual Protection Device. Acoustic Noise Level (LWA) - Measure Unit dB(A): it stands for acoustic noise released in a certain delay of time. This is not submitted to the distance of measurement.

Acoustic Pressure (Lp) - Measure Unit dB(A): it measures the pressure originated by sound waves emission. Its value changes in proportion to the distance of measurement.

The here below table shows examples of acoustic pressure p at different distances from a machine with acoustic noise level LWA of d

Table with 2 columns: p a meter d and p a meters d

PLEASE NOTE: the symbol [LWA logo] when with acoustic noise values, indicates that the device respects noise emission limits according to E directive.




C.C. WELDING

Welding current 2x400A/35% - 2x360A/60% - 2x330A/100%
Starting voltage 68V

C.V. WELDING

Welding current 2x360A/60% - 2x330A/100%
Welding voltage 16 - 36V



SIMULTANEOUS UTILIZATION FACTORS

In case Welding and Generation can be used simultaneously, however, the engine cannot be overloaded. The table below gives the maximum limits to be respected

| | | | | | |
|---------------------------------|-------|------|-------|--------|--------|
| WELDING CURRENT SINGLE POSITION | 400A | 00A | 200A | 100A | 0 |
| AUXILIARY POWER | 25kVA | 0kVA | 5 kVA | 40 kVA | 40 kVA |

| | | | | | |
|---------------------------------|--------|--------|--------|--------|--------|
| WELDING CURRENT DOUBLE POSITION | 2x400A | 2x 00A | 2x200A | 2x100A | 0 |
| AUXILIARY POWER | 10kVA | 20 kVA | 0 kVA | 40 kVA | 40 kVA |

**BATTERY WITHOUT MAINTENANCE**

Connect the cable positive to the pole positive of the battery after having taken away the protection, by properly tightening the clamp.

Check the state of the battery from the colour of the warning light which is in the upper part.

Green colour battery

Lack colour battery to be recharged

White colour battery to be replaced

DO NOT OPEN THE BATTERY.

**LUBRICANT**

Check the level of the engine oil using the oil dipstick. The level should be between the minimum and maximum marks. If necessary, add more oil.

If the air filter is of the oil bath type, fill it with the same oil up to the level indicated on the filter.

RECOMMENDED SAE VISCOSITY GRADES

For the type and viscosity of oil refer to owner's manual for the engine supplied with the machine.

NOTE: Before starting the engine read the instructions in the owner's manual for the engine.

**FUEL**

Fill the tank with good quality diesel fuel.

ATTENTION Diesel fuel is highly inflammable. Before filling the tank, stop the engine. Do not fuel in the presence of open flames.



If fuel is spilled on the engine, clean it immediately before starting up the engine.

**COOLING LIQUID (Water-cooled engines only)**

Pour the cooling liquid through the hole at the top of the radiator until it reaches the opening. For the type of cooling liquid to be used and for maintenance of the cooling system, refer to the engine manual.

**GROUND CONNECTION**

A good ground is obligatory for all models with a ground fault interrupter (E) earth leakage circuit breaker. These protective devices will not protect the operator unless there is a good ground.

Use a good quality ground cable and connect it to the grounding point of the machine. Follow all local rules and or regulations in force.

Machines with Isometer protection do not need to be grounded.

Once the above operations have been completed, the machine can be used.



check daily



NOTE

Do not alter the primary conditions of regulation and do not touch the sealed parts.

STARTING THE ENGINE

1500 1 00 RPM ENGINES

These engines start their normal operating speed.

IGNITION KEY



The ignition key is a part of the E engine protection device and has three positions.

To start the engine introduce the key, turn it clockwise completely, leaving it as soon as the engine starts.


NB.: for safety reason the key must be kept by qualified personel.

Let the engine run for some minutes before drawing the load.



STOPPING THE ENGINE

Before stopping the engine it is compulsory to

disconnect or shut off any loads which are connected to the unit auxiliary outputs.




stop welding.



To stop the engine:




Turn the starter key to the off position.



| os. | Description | os. | Description |
|-----|---------------------------------------|-----|--|
| 9 | Welding socket (+) | 08 | V/A digital instruments PCB and Led V.R.D. PCB |
| 10 | Welding socket (-) | Q7 | Welding selector mode |
| 12 | Earth terminal | T | Welding current regulator |
| 15 | A.C. socket | V4 | Polarity inverter control (Optional) |
| 59A | Engine thermal switch | X1 | Remote control socket |
| 59B | Aux current thermal switch | | |
| 59C | Supply thermal switch wire feeder-42V | | |
| 59F | Fuel injection pump thermal switch | | |
| C2 | Fuel level gauge | | |
| D | Ground fault interrupter (30 mA) | | |
| I3 | Welding scale switch | | |
| M | Hour counter | | |
| M5 | Engine control unit EP5 | | |
| N | Voltmeter | | |


Auxiliary power outlets and thermal circuit breaker

The unit is equipped with auxiliary output sockets three phase and single phase. The voltages depend on the version selected. The three phase socket requires no protection as the asynchronous alternator protects itself. The single phase sockets are supplied with thermal circuit breakers which pop out when overloaded. After they have been activated give them a short time to cool down before re inserting. If they continue to pop out check that the load is not too large for the output of the socket.




Ground fault interrupter

The ground fault interrupter protects the operator from injury in the event of a ground fault. If it is activated, raise the plastic cover and push the lever up to reset.




EP5 engine protection module and starter key

The engine protection module contains the starter key, an emergency stop switch and a set of LEDs which show the status of the alarms. A few seconds after the engine is started the shut down function is inhibited to allow the engine to start. The two thermal switches located below the module protect the starting system and the fuel injection pump thermal switch.



The ignition key has three positions
a
b
c S R with automatic return



Stops the engine at any time. Push the button until the engine stops.

It signals the intervention of the overspeed protection. The optical and acoustic signal is activated, and the engine stopped.

It signals, through the temperature sensor, a high temperature anomaly. The optical and acoustic signal is activated, and the engine stopped. Check the air inlets there must be no obstruction, the cooling liquid if engine is water cooled, the oil level, etc....

It signals, through the pressure sensor, a low oil pressure anomaly. The optical and acoustic signal is activated, and the engine stopped. Check the oil level and, if it is correct, call the Service.


It signals the fuel running out, acoustically with the siren and optically, without stopping the engine the signal lasts until the cause is eliminated.


It signals a failure of the battery charge generator and therefore the battery charging. The visual signal will last without stopping the engine, until the cause is eliminated.

The signal shows that the device is working.

Instruments

Standard instruments include a fuel level gauge, an operating hour counter and a voltmeter for the auxiliary power which shows the three phase voltage. If the voltmeter does not show any voltage check that the ground fault interrupter is inserted. The voltage shown will vary depending on the load and the welding current being drawn. At no load and when not welding, the voltage can be as high as. The auxiliary power cannot be used when it drops below. Optionally an ammeter and a voltmeter for the welding output are available.







GETTING STARTED

SETTING THE WELDING PROCESS

- 1) After having prepared the machine charged the battery, put in oil and fuel the machine is ready for operation. Before starting the engine please note the following: the welder should only be operated by qualified personnel with experience in working with engine driven welders. Check the oil level daily. Fuel should be put in before starting the engine. Before using the welder or the auxiliary power let the engine warm up and before stopping the engine let it run without load to cool down. Refer to the following instructions regarding the function of the various controls on the front panel.



- 2) Start the engine of the welder




- 3) Turn the welding current voltage adjusting knob to the minimum setting.

There is a manual switch for selecting the various welding processes on the welding control panel. There are three processes to choose from: for I welding; for S I welding electrode; for I welding continuous wire. The switch can also be set to stand by first position. In this position there is no current at the welding connections led off. The process can be selected either before or after starting the motor powered welder. After selecting the mode, the LED lights up. If the wirefeeder connector is connected on remote control connector the LED light only when the button torch is pressed.

TIG MODE

Contact starting in TIG position is specifically for TIG welding. To create the arc simply place the tip of the TIG electrode on the piece that requires welding then gently move the tip away. The arc starts automatically and at the same time the welding current rises to the preset value, first using the welding current adjustment knob which is on the lower part of the control panel. The welding current can be adjusted continuously from a minimum of 10A to a maximum which depends on the power of the machine.



WARNING

For E version it is compulsory to accelerate the engine manually.

STICK MODE (Electrode)

Features constant current. There are three stick modes which feature increasing arc forces so that the arc has different levels of penetration according to the electrode and or welding position.

MIG/MAG MODE (continuous wire)

Features constant voltage. All wire type welding processes can be carried out, naked or coated. The voltage can be adjusted using the same knob which adjusts the current in Stick mode. Adjustment is continuous and goes from a minimum of 10V to a maximum of 25V.

Optional remote control

The welding current can also be set from a distance using the optional remote control. Once the remote control is connected to the connector, the current is controlled by the remote control. To return to front panel control remove the connector.

Optional VRD program Voltage Reduction Device (VRD)

When you choose the program stick or stick arc force the open circuit voltage goes up, red light switch on and green light switch off, but only for about 1 second, then the voltage goes down, green light switch on and red light switch off, about 1 second and stop there, until the welder start welding. When you make a short circuit with the stick the voltage immediately goes up, so you can start to welding. VRD don't work with the program TIG.


Inversion of polarity (Optional, available on request)

In order to invert polarity, press the switch on the remote control unit. When selecting inversion the LED switches off and the voltage at the welding socket becomes zero. The power contactor is switched inside the electrical box and the voltage reappears at the welding sockets. The LED switches back on at the same time. The Invert polarity LED on the front panel near the welding current adjuster switches on. You cannot invert polarity in "MIG/MAG" mode.


PROTECTIONS

The welding Digital control features protections for the control and chopper.


1) "ON" LED blinking

 When the engine of the welder is started the control unit automatically goes to the stand by mode for few instants stand by LED on and performs a self diagnosis of the current sensor connector and power source voltage than the last process is loaded on led turned on. In case of malfunction the "ON" LED blinks.

2) Red LED blinking

 The chopper has a thermal protection, which intervenes in case the operating temperature exceeds 150°C. If the protection intervenes, the red LED begins to flash and the welding current voltage goes to zero. In this case do not switch off the welder, since the alternator fan will help cool down the chopper more quickly. After a few minutes, the LED will automatically switch itself off and the welding voltage current will once again be available at the plugs.

3) Red LED continuously lit

 If an anomalous current is detected in the chopper, the control blocks the conversion immediately, the output welding current voltage goes to zero and the red LED lights up. To reset everything, it is necessary to switch off the machine.

If the protections should intervene, it is best to immediately contact the nearest authorised Service Centre.

DIGITAL INSTRUMENTS

Two digital instruments showed the operating value of welding current and welding voltage.

WIRE FEEDER CONNECTED WITH REMOTE CONTROL CONNECTOR



Wire feeder connection

Connect the wire feeder to the welder with the welder turned off

Welding cable between the machine's welding plug and the wire feeder.
 Welding cable between the machine's welding plug and the piece to be welded.
 Control power cable between the machine's connector and the corresponding connector on the wire feeder.

Start the machine welder

The RED will be off and will turn on only when there is voltage at the welding plugs and therefore at the wire.
 The voltage is only present when the welding torch button is pressed.
 The setting of the welding voltage is done using the knob on the wire feeder.
 The adjusting knob on the welder is automatically inhibited.



WARNING

You can use the wire feeder only by respecting the pin configuration as shown on the below mentioned table.


“WIRE FEEDER NOT CONNECTED WITH REMOTE CONTROL CONNECTOR”

Welding voltage is always present on welding sockets and also RD is active.

Welding cable between the machine's welding plug and the wire feeder.
 Welding cable between the machine's welding plug and the piece to be welded.

The setting of the welding voltage is done by using the knob on the front panel.

| NAME OF CONTACT | DESCRIPTION |
|------------------|---|
| electric ground | potentiometer R terminal a |
| | potentiometer R central b |
| d.c. | potentiometer R terminal c |
| D | short circuit with contact |
| E d.c. | switch Polarity Inverter lose for negative polarity |
| | Return from switch on welding gun, phase a.c. |
| H welding ground | welding ground for d.c. voltmeter on wire feeder |
| I a.c. | voltage supply for wire feeder |
| | a.c. |



The remote control PHG1A, which regulates the welding current in the CC (STICK welding) mode and the welding voltage in the CV (MIG/MAG welding) mode, is connected to the front panel by means of a multipole connector.

When the remote control is connected to the remote control connector (8), it is functional and automatically excludes the front panel regulation.

The remote control can also be connected to the connector on the wire feeder front panel but in this case it is necessary to switch the wire feeder commutator so it can operate.

The polarity inverter (64A), if installed, can be operated from the remote control.

Adjust the welding current control knob to the correct current for the diameter and type of electrode being welded.



ATTENTION

When the PHG1A is not used, it is necessary to disconnect the multipole connector



WARNING



**MOVING
PARTS
can injure**

- Have **authorized** personnel do maintenance and troubleshooting work.
- Stop the engine before doing any work inside the machine. If for any reason the machine must be operated while working inside, **pay attention** moving parts, hot parts exhaust manifold and muffler, etc. electrical parts which may be unprotected when the machine is open.
- Remove guards only when necessary to perform maintenance, and replace them when the maintenance requiring their removal is complete.
- Use suitable tools and clothes.
- Do not modify the components if not authorized.



**HOT surfaces
can
injure you**


MAINTENANCE OF THE MACHINE

Maintenance refers to all operations regarding the control and replacement of mechanical and electrical parts subject to wear. In addition it refers to the control and topping up or replacement of fluids such as fuel, and the regular cleaning of the machine.

Repairs refers to the substitution of worn or damaged parts and repairs should be carried out by authorized Service Centers.

Refer to the Engine manufacturer's manual for the maintenance instructions for the engine. Periodic maintenance should be performed according to the schedule shown in this manual.

On a regular basis check that there are no obstructions in the aspiration exhaust ducts of the alternator, the engine or the housing which could restrict the flow of cooling air.





BATTERY WITHOUT MAINTENANCE

DO NOT OPEN THE BATTERY

The battery is charged automatically from the battery charger circuit supplied with the engine.

Check the state of the battery from the colour of the warning light which is in the upper part.

- Green colour: battery OK
- Black colour: battery to be recharged
- White colour: battery to be replaced

DRY AIR FILTER

Replace the air filter cartridge every 200 hours under normal conditions and every 100 hours in dusty environments.

RADIATOR

Check the liquid level in the radiator regularly and refill as required. In the fall check the amount of antifreeze and add required to prevent freezing during the winter months.

ASYNCHRONOUS ALTERNATOR

No maintenance is necessary, as the alternator has no brushes or slip rings, and there are no devices for regulation of the output.

WARNING LABELS AND DECALS

Check warning labels and decals once a year and replaced if missing or unreadable.

CABLES AND CONNECTIONS


Periodically check the condition of the cables and tighten the connections.



IMPORTANT



When carrying out maintenance operations be careful to avoid polluting the environment with the materials used during maintenance. Follow all local health and safety regulations.





WARNING AND MAINTENANCE

KHM 2x400 PS

**M
44.2**

IMPORTANT



Have qualified personnel do maintenance and troubleshooting work.

Stop the engine before doing any work inside the machine. If for any reason the machine must be operated while working inside, pay attention to rotating parts and hot surfaces which may be unprotected when the machine is open.



Remove guards only when necessary to perform maintenance, and replace them when the maintenance requiring their removal is complete.




WARNING



ARC WELDING SAFETY PRECAUTIONS

WARNING: PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH



FUMES AND GASES CAN BE DANGEROUS

Use ventilator or exhaust to system remove fumes from breathing zone.

FOR ENGINE POWERED EQUIPMENT

Moving parts can injure.
Hot surface can hurt you.

BATTERY

Sulfuric acid is corrosive; protect hands, eyes and clothes, etc.

ELECTRIC SHOCK CAN KILL

Do not touch electrically live parts or electrodes with skin or wet clothing.
Insulate yourself from work and ground.
Always wear dry insulating gloves.

ARC RAYS CAN BURN

NOISE CAN DAMAGE HEARING

Wear eyes, ear and body protection

WELDING SPARKS CAN CAUSE FIRE OR EXPLOSION

Keep flammable material away
Do not weld containers which have held flammable materials.

DIESEL IS VERY FLAMMABLE

PERIODICAL MAINTENANCE

| TYPE OF MAINTENANCE | | TIME PERIOD | EVERY DAY | EVERY 100 HOURS | EVERY 150 HOURS | EVERY 300 HOURS | EVERY 500 HOURS | EVERY 1000 HOURS | EVERY 2000 HOURS |
|---------------------|---|-------------|-----------|-----------------|-----------------|-----------------|-----------------|------------------|------------------|
| | | | | | | | | | |
| CHECK | Air filter condition Crankcase oil level Battery electrolyte level Amount of coolant | | • | • | | | | | |
| | Belt - Fan and fan belt Tighten nuts and bolts Valves, rocker arms Injector regulation Water in the fuel pre-filter | | • | • | • | • | • | • | • |
| CLEANING | Filters Dry air filter Fuel pump filter | | • | • | | | | | |
| | Radiator Air passages Fan | | • | | | | • | | |
| REPLACEMENT | Injectors Fuel tank | | | | | | • | • | |
| | Change oil Crankcase (1) | | | | • | | | | |
| REPLACEMENT | Cartridge Dry air filter Fuel filter Oil filter (1) | | | | | • | • | | |
| | Brushes, starter motor Fan belt | | | | | | | | • |

1) Replace oil and oil filter after the first 50 working hours.

Note: Under extreme operating conditions (frequent stops and starts, dusty environment, cold weather, extended periods of no load operation, fuel with over 0.5% sulphur content) do maintenance more frequently. Check condition of cables and connections daily!

For detailed maintenance instructions refer to manuals.



STORAGE

KHM

M
45

In case the machine will not be used for more than 30 days, it should be stored in a suitable area where it is protected from the elements to prevent rusting, corrosion and other damage to the machine.

DIESEL ENGINES

If the machine will be stored for short periods of time it is advisable to start the engine every 7 days and operate it for 15 minutes under load. This will distribute the oil, recharge the battery and prevent blockage of the injection system.

For long periods of storage, refer to the engine manufacturer's manual.


Clean the machine carefully.


Cover the machine with a plastic cover and store in a dry place.



IMPORTANT

When storing the machine, please read the instructions carefully. Do not use the machine for more than 15 minutes every 7 days. For long periods of storage, refer to the engine manufacturer's manual.







C

Запасные части можно заказать у ближайшего к Вам представителя фирмы E смотри обратную сторону обложки
 Для упрощения отправки и гарантии правильности запросов в момент заказа запчастей необходимо уточнить тип машины и
 заводской номер а также указать наименование и код запасной части по таблице запчастей

E

E

E


E

E

E

E

C



| | | | | | | | | | |
|------|----------------|---------------------------|-------|------------------------|-----------|-------------|--|----|--|
| ESAB | | ESAB Welding Equipment AB | | SE-695 81 Laxå, Sweden | | Made in EEC | | CE | |
| TYPE | KHM | SERIAL N° | 0794 | | IEC 974-1 | | | | |
| S | X | 30% | 60% | 100% | | | | | |
| U | W(A) | | | | | | | | |
| U | V(V) | | | | | | | | |
| S | W(A) | | | | | | | | |
| U | V(V) | | | | | | | | |
| G | KVA | | | | | | | | |
| PF | V (V) | | | | | | | | |
| | I(A) | | | | | | | | |
| | n | RPM | n | RPM | IP | | | | |
| | n _s | RPM | Ptmax | KW | I.L.C. | | | | |

При заказе запасных частей указать

P

E

P

- 1 * /
- 2 * /
- ◆ /


заводской номер

модель сварочного агрегата и/или генератора

страницу для ссылки


количество

- ☞ *
- * требуемые данные приведены на табличке с паспортными данными машины
- *
- *
- *
- *




| | | | | | |
|-----------|---|------------|---------------|----------|---|
| B | Sostituto motore Perkins 1003A-33TG1 con motore Perkins 1103C-33TG3 | 14.01.2007 | | | |
| A | Aggiunto optional PRH6. | 16.11.2007 | | | |
| Exp. | Modifica | Data | Dis. | Appr. | |
| From Page | Denominazione: | From Page | Dis. n° | Appr. n° | |
| To Page | Denominazione: | To Page | Dis. n° | Appr. n° | |
| | Engine Perkins 1103C-33TG3 | | 78410.prg | 2 | 7 |
| | Macchina: | | Dis. n° | Appr. n° | |
| | KHM 2x400 PS-CT | | 78410.S.010-B | | |
| | Macchine: | | Dis. n° | Appr. n° | |
| | | | 78410.S.010-B | | |


OPTIONAL:
894100157




| Sp. Exp. | Modifica | Data | Dis. | Appr. |
|-----------|---------------------------------------|-------------------------|--------------------------|--------------------------|
| From Page | Denominazione: | Date | Desi. | Appr. |
| To Page | Denominazione: | Date | Desi. | Appr. |
| | Aux. (400T x 2/230M x 3110CTE x 3) DT | 78410.prg | 3 | 7 |
| | Macchina: KHM 2x400 PS-CT | Disegnatore: 09.10.2002 | Disegnatore: 78400.S.020 | Disegnatore: 78400.S.020 |




| | | | | | |
|--------------------|------------------------------|--------------------|-------------------|----------------------|-------------|
| Exp. Exp. | Modifica | | | Dis. Desi. | Appr. Appr. |
| Da Pag. From Page | Denominazione: Denomination: | Projecto: Project: | di n° di n° | Page n° of n° | |
| Ala Pag. To Page | Welding Power (station 1) | 78410.prg | 4 | 7 | |
| Macchina: Machine: | Disegnatore: Designer: | Data: Date: | Dis. n°: Dwg. n°: | Approvato: Approved: | |
| | KHM 2x400 PS-CT | 31.01.2008 | 78410.S.030 | | |





| | | | | |
|--------------------|------------------------------|--------------------|----------------------|-------------|
| Exp. Exp. | Modifica | Data Date | Dis. Desi. | Appr. Appr. |
| Da Pag. From Page | Denominazione: Denomination: | Projecto: Project: | Page n° of n° | di n° of n° |
| Alla Pag. To Page | Welding Power (station 2) | 784 10.prg | 5 | 7 |
| Macchina: Machine: | KHM 2x400 PS-CT | Dis. n°: Dwg. n°: | Approvato: Approved: | |
| | | 31.01.2008 | 78410.S.031 | |



| | | | | | | | | | |
|------|--------------|------------------------------------|-----------------------------|------------|---------------|---------------|---------------|---------------|---------------|
| A | | Aggiunto commutatore di scala (I3) | | 01.06.2006 | | Dis. Desi. | | Appr. Appr. | |
| Exp. | Modifica | Da Pag. | Denominazione: | Data | Projecto: | Page n° | Dis. n° | Page n° | Appr. n° |
| | Modification | From Page | Denomination: | | Project: | 78410.prg | 78410.prg | 6 | 7 |
| | | | Welding Control (station 1) | | | | | | |
| | | Alla Pag. | Macchina: | Data: | Dis. n°: | Dis. n°: | Dis. n°: | Dis. n°: | Dis. n°: |
| | | To Page | Machine: | Date: | Dwg. n°: | Dwg. n°: | Dwg. n°: | Dwg. n°: | Dwg. n°: |
| | | | KHM 2x400 PS-CT | 29.10.2004 | 78401.S.040-A | 78401.S.040-A | 78401.S.040-A | 78401.S.040-A | 78401.S.040-A |



| | | | | | | | | | |
|------------------------------|--|------------------------------------|--|--------------------|--|-----------------------------|--|----------------------|--|
| A | | Aggiunto commutatore di scala (I3) | | 01.06.2006 | | Dis. Desi. | | Appr. Appr. | |
| Esp. Esp. | | Modifica | | Data Date | | Dis. Desi. | | Appr. Appr. | |
| Da Pag. From Page | | Denominazione: Denomination: | | Progetto: Project: | | Pag. n° di n° Page n° of n° | | 7 7 | |
| To Page | | Welding Control (station 2) | | 78410.prg | | 7 | | 7 | |
| Alla Pag. Macchina: Machine: | | Dis. n°: Dwg. n°: | | Dis. n°: Dwg. n°: | | 78401.S.041-A | | Approvato: Approved: | |
| 29.10.2004 | | 29.10.2004 | | 78401.S.041-A | | | | | |









ED

| Item no. | Q.ty | Ordering no. | Denomination | NOTES | C |
|----------|------|--------------|------------------------------------|-------------------------------------|---|
| 1 | 1 | 0794000149 | RING FIXING FAN | | |
| 2 | 1 | 0794000320 | FAN | | |
| 3 | 1 | 0794000354 | ALTERNATOR AIR CONVEYOR | | |
| 4 | 1 | 0794000355 | ALTERNATOR COVEER | | |
| 5 | 1 | 0794000319 | HOUSING | | |
| 6 | 1 | 0794000318 | STATOR | | A |
| 7 | 1 | 0794000084 | RING, SEEGER | | |
| 8 | 1 | 0794000151 | BEARING | | |
| 9 | 1 | 0794000356 | SHAFT ROTOR (COMPL.) | | |
| 10 | 1 | | PERKINS ENGINE 1103C-33TG3 | | |
| 11 | 3 | 0794000293 | ALTERNATOR COVER SUPPORT | | |
| 12 | 1 | 0794000358 | ALTERNATOR BRACKET (COMPL.) | | |
| 13 | 2 | 0794000366 | COVERS BRACKET | | |
| 14 | 1 | 0794000359 | BRACKET LIFT | | |
| 15 | 1 | 0794000448 | ENGINE AIR EXHAUST SITE | | |
| 16 | 1 | 0794000449 | REACTOR HOLDING STEEL SHEET | | |
| 22 | 2 | 0794000211 | CAPACITOR BOX BRACKET | | |
| 23 | 6 | 0794000109 | CAPACITOR BOX BRACKET | | |
| 24 | 4 | 0794000025 | CAPACITOR BOX | 3x80 UF | C |
| 25 | 2 | 0794000450 | CAPACITOR BOX FIXING PLATE (COMPL) | | |
| 26 | 4 | 0794000369 | SUPPORT BRACKET REACTOR | Delivered up to 538 - XXX - XXXX | |
| 27 | 2 | 0794000370 | INDUCTOR | Delivered up to 538 - XXX - XXXX | W |
| 27 | 2 | 0794000491 | LEVEL REACTOR | Delivered from 623 - XXX - XXXX | W |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

C = component designation in the electrical system.





(D)
(GB) Spare parts
(F)


KHM 2x400 PS

ED
14.1

ED14

| Item no. | Q.ty | Ordering no. | Denomination | NOTES | C |
|----------|------|--------------|--|-------------------------------------|----|
| 1 | 1 | 0794000371 | ENGINE SIDE FRONT PANEL | | |
| 2 | 3 | 0794000301 | CIRCUIT BREAKER | 10A/250V | P4 |
| 3 | 2 | 0794000330 | W.D.C. | | R |
| 4 | 4 | 0794000372 | LATCH X FRONT COVER | | |
| 5 | 3 | 0794000381 | CIRCUIT BREAKER | 30A/250V | P4 |
| 6 | 13 | 0794000373 | TERMINAL | 4mmq | |
| 7 | 4 | 0794000374 | PLATE | | |
| 8 | 1 | 0794000097 | RELAY | | N3 |
| 9 | 1 | 0794000375 | TERMINAL GUIDE | order q.ty in meter | |
| 10 | 1 | 0794000098 | TERMINAL BOARD | | |
| 11 | 2 | 0794000034 | EEC SOCKET 230V 16A | | H |
| 12 | 1 | 0794000377 | SOCKET HOLDER PANEL, WELDER SIDE | | |
| 13 | 2 | 0794000070 | EEC SOCKET 400V 32A | | G |
| 15 | 2 | 0794000019 | WELDING SOCKET (+) | | Z |
| 16 | 2 | 0794000020 | WELDING SOCKET (-) | | Z |
| 17 | 2 | 0794000380 | SHUNT | | X |
| 19 | 1 | 0794000161 | GROUND FAULT INTERRUPTOR (GFI) | | D |
| 20 | 1 | 0794000162 | VOLTMETER | | N |
| 23 | 2 | 0794000382 | FRONT COVER LOCK | | |
| 24 | 2 | 0794000383 | ELECTRICAL BOARD KEY | | |
| 25 | 1 | 0794000165 | FUEL LEVEL INDICATOR | | C2 |
| 27 | 1 | 0794000063 | HOURLY METER | 230V 50Hz | M |
| 28 | 1 | 0794000163 | ENGINE PROTECTION EP5 | | M5 |
| 29 | 2 | 0794000384 | WELDING VOLTMETER 100V DC | Delivered up to 623 - XXX - XXXX | V |
| 30 | 2 | 0794000385 | WELDING AMMETER 600A, 90mV | Delivered up to 623 - XXX - XXXX | S |
| 31 | 1 | 0794000386 | ELECTRICAL BOX ENGINE SIDE | | |
| 32 | 1 | 0794000387 | FRONT PANEL GENERATION SIDE | | |
| 33 | 1 | 0794000388 | ELECTRICAL BOX GENERATION SIDE | | |
| 34 | 1 | 0794000510 | SOCKETS HOLDER FRONT PANEL | | |
| 35 | 2 | 0794000350 | HALL SENSOR | | W6 |
| 36 | 2 | 0794000351 | WELDING PCB TRANSFORMER | | E |
| 38 | 1 | 0794000508 | LED V.R.D. PCB and V/A DIGITAL INSTRUMENTS PCB | Delivered from 802 - XXX - XXXX | O8 |
| 39 | 2 | 0794000307 | EEC SOCKET 110V 16A | | I |
| 40 | 1 | 0794000121 | EEC SOCKET 110V 32A | | I |
| 41 | 1 | 0794000069 | EEC SOCKET 230V 32A | | H |
| 42 | 4 | 0794000057 | CIRCUIT BREAKER | 15A | P4 |
| | | | | | |
| | | | | | |
| | | | | | |

C = component designation in the electrical system.





D

GB

F

Spare parts


KHM 2x400 PS

ED
8.1

ED

| Item no. | Q.ty | Ordering no. | Denomination | NOTES | C |
|----------|------|--------------|-------------------------------|------------|----|
| 1 | 1 | 0794000390 | COVER GRATE | | |
| 2 | 1 | 0794000391 | REAR COVER | | |
| 3 | 1 | 0794000392 | FUEL COVER | | |
| 4 | 1 | 0794000393 | PIPE | | |
| 5 | 1 | 0794000394 | COVER | | |
| 6 | 1 | 0794000107 | CAP, FUEL TANK | | |
| 7 | 1 | 0794000395 | TIE-ROD | | |
| 8 | 1 | 0794000396 | FUEL LEVEL SENSOR | | G1 |
| 9 | 4 | 0794000343 | VIBRATION DAMPER | | |
| 10 | 1 | 0794000451 | BASE | | |
| 11 | 1 | 0794000446 | BATTERY (Without maintenance) | 12V 100 Ah | S1 |
| 12 | 1 | 0794000398 | BATTERY BRACKET | | |
| 13 | 1 | 0794000452 | FUEL TANK | | |
| 14 | 1 | 0794000453 | EXHAUST PIPE | | |
| 15 | 1 | 0794000454 | GASKET | | |
| 16 | 1 | 0794000361 | SUPPORT FILTER | | |
| 17 | 1 | 0794000455 | COCK | | |
| 18 | 1 | 0794000456 | OLEODYNAMIC NIPPLE | | |
| 19 | 1 | 0794000190 | OIL EXHAUST TUBE | | |

C = component designation in the electrical system.





ED

| Item no. | Q.ty | Ordering no. | Denomination | NOTES | C |
|----------|------|--------------|---------------------------------|-------------------------------------|----|
| 1 | 1 | 0794000400 | RIGHT SIDE ELECTRICAL BOX COVER | | |
| 2 | 2 | 0794000353 | CHOPPER BRIDGE | | Y |
| 3 | 2 | 0794000352 | R.C. NET (VRD) | Delivered up to 538 - XXX - XXXX | R7 |
| 3 | 2 | 0794000481 | R.C. NET (VRD) | Delivered from 623 - XXX - XXXX | R7 |
| 4 | 1 | 0794000401 | INTAKE CASE (COMPL.) | | |
| 5 | 1 | 0794000402 | EMERGENCY PUSH BUTTON STOP | | L5 |
| 6 | 1 | 0794000403 | FRONT COVER (COMPL.) | | |
| 7 | 4 | 0794000404 | SUPPORT BRACKET DIODE BRIDGE | | |
| 8 | 4 | 0794000405 | SUPPORT BRACKET ELECTRIC BOX | | |
| 9 | 2 | 0794000406 | ELECTRICAL DEVICES HOLDING BOX | | |
| 10 | 1 | 0794000457 | TOP COVER | | |
| 11 | 1 | 0794000408 | INSTRUMENTS SIDE | | |
| 12 | 4 | 0794000409 | FIXING BRACKET DOOR SCREEN | | |
| 13 | 1 | 0794000410 | AIR INTAKE BOX | | |
| 14 | 2 | 0794000411 | GLASS COVER | | |
| 15 | 1 | 0794000412 | COVER COMMANDS SIDE | | |
| 16 | 4 | 0794000413 | HANDLE | | |
| 17 | 2 | 0794000414 | MIDDLE COVER | | |
| 18 | 10 | 0794000176 | LATCH | | |
| 19 | 1 | 0794000415 | GASKET | | |
| 20 | 1 | 0794000416 | EXHAUST MUFFLER | | |
| 21 | 1 | 0794000417 | RADIATOR COVER CAP | | |
| 22 | 1 | 0794000146 | TIE-ROD | | |
| 23 | 1 | 0794000418 | FLANGE FOR EXHAUST PIPE | | |
| 24 | 1 | 0794000419 | CAP | | |
| 25 | 1 | 0794000458 | SOCKET PROTECTING BOX | | |
| 26 | 1 | 0794000459 | THERMAL PROTECTION | | |

C = component designation in the electrical system.






(D)


(GB)

(F)

KIT DECAL 0794 999 859


KHM 2x400 PS





| Item no. | Q.ty | Ordering no. | Denomination | NOTES | C |
|----------|------|--------------|-------------------------------|-------|---|
| 1 | 1 | 0794000424 | <i>KIT SITE TOW</i> | | |
| 2 | 1 | 0794000426 | <i>AXLE</i> | | |
| 3 | 1 | 0794000427 | <i>WHEEL</i> | | |
| 4 | 1 | 0794000425 | <i>KIT WHEELS AND HANDLES</i> | | |
| | | | | | |
| | | | | | |

C = component designation in the electrical system.



| Item no. | Q.ty | Ordering no. | Denomination | NOTES | C |
|----------|------|--------------|---------------------------|-------|----|
| 3 | 1 | 0794000278 | FEMALE CONNECTOR | | Y1 |
| 4 | 1 | 0794000420 | REMOTE CONTROL CABLE | | |
| 5 | 1 | 0794000206 | KNOB, REGULATOR COMPLETE | | |
| 7 | 1 | 0794000207 | WELDING CURRENT REGULATOR | | A2 |
| 8 | 1 | 0794000280 | BOX TCPL3 | | |
| 9 | 1 | 0794000281 | REMOTE CONTROL HANDLE | | |
| 11 | 1 | 0794000421 | REMOTE CONTROL ASSY | | |
| 13 | 1 | 0794000422 | CAP | | |
| 15 | 1 | 0794000423 | COMMUTATOR | | U4 |

C = component designation in the electrical system.

ESAB subsidiaries and representative offices

Europe

AUSTRIA

ESAB Ges.m.b.H
Vienna--Liesing
Tel: +43 1 888 25 11
Fax: +43 1 888 25 11 85

BELGIUM

S.A. ESAB N.V.
Brussels
Tel: +32 2 745 11 00
Fax: +32 2 726 80 05

THE CZECH REPUBLIC

ESAB VAMBERK s.r.o.
Prague
Tel: +420 2 819 40 885
Fax: +420 2 819 40 120

DENMARK

Aktieselskabet ESAB
Copenhagen--Valby
Tel: +45 36 30 01 11
Fax: +45 36 30 40 03

FINLAND

ESAB Oy
Helsinki
Tel: +358 9 547 761
Fax: +358 9 547 77 71

FRANCE

ESAB France S.A.
Cergy Pontoise
Tel: +33 1 30 75 55 00
Fax: +33 1 30 75 55 24

GERMANY

ESAB GmbH
Solingen
Tel: +49 212 298 0
Fax: +49 212 298 204

GREAT BRITAIN

ESAB Group (UK) Ltd
Waltham Cross
Tel: +44 1992 76 85 15
Fax: +44 1992 71 58 03
ESAB Automation Ltd
Andover
Tel: +44 1264 33 22 33
Fax: +44 1264 33 20 74

HUNGARY

ESAB Kft
Budapest
Tel: +36 1 20 44 182
Fax: +36 1 20 44 186

ITALY

ESAB Saldatura S.p.A.
Mesero (Mi)
Tel: +39 02 97 96 81
Fax: +39 02 97 28 91 81

THE NETHERLANDS

ESAB Nederland B.V.
Utrecht
Tel: +31 30 248 59 22
Fax: +31 30 248 52 60

NORWAY

AS ESAB
Larvik
Tel: +47 33 12 10 00
Fax: +47 33 11 52 03

POLAND

ESAB Sp.z.o.o.
Warszaw
Tel: +48 22 813 99 63
Fax: +48 22 813 98 81

PORTUGAL

ESAB Lda
Lisbon
Tel: +351 1 837 1527
Fax: +351 1 859 1277

SLOVAKIA

ESAB Slovakia s.r.o.
Bratislava
Tel: +421 7 44 88 24 26
Fax: +421 7 44 88 87 41

SPAIN

ESAB Ibérica S.A.
Alcobendas (Madrid)
Tel: +34 91 623 11 00
Fax: +34 91 661 51 83

SWEDEN

ESAB Sverige AB
Gothenburg
Tel: +46 31 50 95 00
Fax: +46 31 50 92 22

ESAB International AB

Gothenburg
Tel: +46 31 50 90 00
Fax: +46 31 50 93 60

SWITZERLAND

ESAB AG
Dietikon
Tel: +41 1 741 25 25
Fax: +41 1 740 30 55

North and South America

ARGENTINA

CONARCO
Buenos Aires
Tel: +54 11 4 753 4039
Fax: +54 11 4 753 6313

BRAZIL

ESAB S.A.
Contagem--MG
Tel: +55 31 333 43 33
Fax: +55 31 361 31 51

CANADA

ESAB Group Canada Inc.
Mississauga, Ontario
Tel: +1 905 670 02 20
Fax: +1 905 670 48 79

MEXICO

ESAB Mexico S.A.
Monterrey
Tel: +52 8 350 5959
Fax: +52 8 350 7554

USA

ESAB Welding & Cutting
Products
Florence, SC
Tel: +1 843 669 44 11
Fax: +1 843 664 44 58

Asia/Pacific

AUSTRALIA

ESAB Australia Pty Ltd
Ermington
Tel: +61 2 9647 1232
Fax: +61 2 9748 1685

CHINA

Shanghai ESAB A/P
Shanghai
Tel: +86 21 6539 7124
Fax: +86 21 6543 6622

INDIA

ESAB India Ltd
Calcutta
Tel: +91 33 478 45 17
Fax: +91 33 468 18 80

INDONESIA

P.T. Esabindo Pratama
Jakarta
Tel: +62 21 460 01 88
Fax: +62 21 461 29 29

MALAYSIA

ESAB (Malaysia) Snd Bhd
Selangor
Tel: +60 3 703 36 15
Fax: +60 3 703 35 52

SINGAPORE

ESAB Singapore Pte Ltd
Singapore
Tel: +65 861 43 22
Fax: +65 861 31 95

ESAB Asia/Pacific Pte Ltd

Singapore
Tel: +65 861 74 42
Fax: +65 863 08 39

SOUTH KOREA

ESAB SeAH Corporation
Kyung--Nam
Tel: +82 551 289 81 11
Fax: +82 551 289 88 63

THAILAND

ESAB (Thailand) Ltd
Samutprakarn
Tel: +66 2 393 60 62
Fax: +66 2 748 71 11

UNITED ARAB EMIRATES

ESAB Middle East
Dubai
Tel: +971 4 338 88 29
Fax: +971 4 338 87 29

Representative offices

BULGARIA

ESAB Representative Office
Sofia
Tel/Fax: +359 2 974 42 88

EGYPT

ESAB Egypt
Dokki--Cairo
Tel: +20 2 390 96 69
Fax: +20 2 393 32 13

ROMANIA

ESAB Representative Office
Bucharest
Tel/Fax: +40 1 322 36 74

RUSSIA - CIS

ESAB Representative Office
Moscow
Tel: +7 095 937 98 20
Fax: +7 095 937 95 80
ESAB Representative Office
St Petersburg
Tel: +7 812 325 43 62
Fax: +7 812 325 66 85

Distributors

For addresses and phone numbers to our distributors in other countries, please visit our home page

www.esab.com



ESAB AB SSC Nordic Region
Box 80040
S-402 77 Göteborg
SWEDEN
Phone + 46 31 509000
Fax +46 31 509195



www.esab.com